



62A Series Balances For Jambliners

1/2" RIBBED CHANNEL BALANCE FOR JAMBLINERS COMMONLY REFERRED TO AS D70 BALANCES.




Ribbed Balance



End view of channel shape of ribbed balances

Ordering Information

- 1) Measure metal channel length. Do not include any attached ends.
- 2) Check number stamped on channel. (e.g. 16, 16HD, 16TG, etc.)
- 3) Select our corresponding part number from the chart below.
- 4) Identify the appropriate end bracket to be attached from illustration at right of chart. Select -2, -5, -7, -8, -9, -12, -14, -17.
- 5) Note -2, -8, -12 are available in white and black. White will automatically be attached to regular balances; black will automatically be attached to HD, TG and XHD balances.



62-502 White

General Information


- 1) In order to remove 62A series balances, you must first remove all window trim and remove sash along with jambliners. Balances can then be slid out of jambliner sleeve once parts are moved to the release position. (Forcing balances out of jambliner pocket will most likely destroy vinyl extrusion!)
- 2) Balances can be special ordered in beige or white finishes. Contact your account manager for part numbers.

End Brackets

Add suffix to complete part number.


Length of Metal Channel	Number Stamped on Balance	Our Part Number	Length of Metal Channel	Number Stamped on Balance	Our Part Number
13"	12 or 12R	62A-12-	30"	29 or 29R	62A-29-
13"	12HD	62A-12HD-	30"	29HD	62A-29HD-
14"	13 or 13R	62A-13-	30"	29TG or 29XHD	62A-29TG-
14"	13HD	62A-13HD-	31"	30 or 30R	62A-30-
15"	14 or 14R	62A-14-	31"	30HD	62A-30HD-
15"	14HD	62A-14HD-	31"	30TG or 30XHD	62A-30TG-
16"	15 or 15R	62A-15-	32"	31 or 31R	62A-31-
16"	15HD	62A-15HD-	32"	31HD	62A-31HD-
17"	16 or 16R	62A-16-	32"	31TG or 31XHD	62A-31TG-
17"	16HD	62A-16HD-	33"	32 or 32R	62A-32-
18"	17 or 17R	62A-17-	33"	32HD	62A-32HD-
18"	17HD	62A-17HD-	33"	32TG or 32XHD	62A-32TG-
19"	18 or 18R	62A-18-	34"	33 or 33R	62A-33-
19"	18 HD	62A-18HD-	34"	33HD	62A-33HD-
20"	19 or 19R	62A-19-	34"	33TG or 33XHD	62A-33TG-
20"	19HD	62A-19HD-	35"	34 or 34R	62A-34-
21"	20 or 20R	62A-20-	35"	34HD	62A-34HD-
21"	20HD	62A-20HD-	35"	34TG or 34XHD	62A-34TG-
21"	20TG or 20XHD	62A-20TG-	36"	35 or 35R	62A-35-
22"	21 or 21R	62A-21-	36"	35HD	62A-35HD-
22"	21HD	62A-21HD-	36"	35TG or 35XHD	62A-35TG-
22"	21TG or 21XHD	62A-21TG-	37"	36 or 36R	62A-36-
23"	22 OR 22R	62A-22-	37"	36HD	62A-36HD-
23"	22HD	62A-22HD-	37"	36TG or 36XHD	62A-36TG-
23"	22TG or 22XHD	62A-22TG-	38"	37 or 37R	62A-37-
24"	23 or 23R	62A-23-	38"	37HD	62A-37HD-
24"	23HD	62A-23HD-	38"	37TG or 37XHD	62A-37TG-
24"	23TG or 23XHD	62A-23TG-	39"	38 or 38R	62A-38-
25"	24 or 24R	62A-24-	39"	38HD	62A-38HD-
25"	24HD	62A-24HD-	39"	38TG or 38XHD	62A-38TG-
25"	24TG or 24XHD	62A-24TG-	40"	39 or 39R	62A-39-
26"	25 or 25R	62A-25-	40"	39HD	62A-39HD-
26"	25HD	62A-25HD-	40"	39TG or 39XHD	62A-39TG-
26"	25TG or 25XHD	62A-25TG-	41"	40 or 40R	62A-40-
27"	26 or 26R	62A-26-	41"	40HD	62A-40HD-
27"	26HD	62A-26HD-	41"	40TG or 40XHD	62A-40TG-
27"	26TG or 26XHD	62A-26TG-	42"	41 or 41R	62A-41-
28"	27 or 27R	62A-27-	42"	41HD	62A-41HD-
28"	27HD	62A-27HD-	42"	41TG or 41XHD	62A-41TG-
28"	27TG or 27XHD	62A-27TG-	43"	42 or 42R	62A-42-
29"	28 or 28R	62A-28-	43"	42HD	62A-42HD-
29"	28HD	62A-28HD-	43"	42TG or 42XHD	62A-42TG-
29"	28TG or 28XHD	62A-28TG-			

-2




62-502
White

-5




900-18354
Die Cast

-9




62-530
w/Adjustment Screw

-12



62-520
White


-14



62-528
Die Cast


62-526
Attached Separately

-16



62-682
White

-17



62-684B
Black